

INSTRUCTIONS

PRO RACK: REPLACING A WHEEL

TOOLS

Hexagonal Screwdriver (4mm)
Flathead Screwdriver (thinnest possible)



We recommend performing these actions with the PRO Rack FOLDED and PLACED on a table covered with a protective surface. (The table will be grateful for your care).

Bag PRO replacement kit



1 Wheel / 2 Protective covers
1 Male-Female Assembly Screw



Insert the flathead screwdriver DELICATELY into the gap between the protective cover and the plastic wheel support.
GENTLY action = No damage!



Lever the screwdriver to remove the protective cover.

Repeat **1** & **2** on the OTHER side.



Unscrew the screw. You may need to hold the other side of the screw with your finger.



When both parts of the screw are removed, you can take OFF the wheel.
All parts MUST be changed.



Place the new wheel from your replacement kit. Locate the side with the notch.



Place the female part of the screw in the hole, aligning its position with the notch to prevent it from moving.



Place the male part of the screw on the other side and tighten completely.



Place the new protective covers from your replacement kit. You may need to press FIRMLY.

Bag PRO

TOP BAGAGE INTERNATIONAL Group
ZA La Gautrais 7 rue des Tisserands
35360 Montauban-de-Bretagne
France

HERE WE GO AGAIN!